

INSTALLING NYLON GLIDE CAPS ONTO CARPET GLIDES

Tools needed: Gloves

1: Prior to installation, *heat* the nylon glide caps in one of the following ways to make them more pliable:

- A. Place the nylon glide caps into boiling water for two minutes.**
- B. Heat the nylon glide caps with dry heat using a heat gun.**

USE CAUTION WHEN HEATING. DO NOT MELT OR DISFIGURE THE NYLON GLIDE CAP.

2: While wearing gloves, push the nylon cap over the end of the metal carpet glide (see illustrations below). If needed, use a rubber mallet to gently seat the nylon cap onto the carpet glide.

