Caster Removal & Replacement for Gasser Woodline Chairs • GASSER CHAIR COMPANY, INC.



TOOLS NEEDED:

- 1. Rawhide hammer or rubber mallet
- Crowsfoot tack puller or large screwdriver



Step 3
Using a firm, downward force on handle—caster will lift from socket.



Step 6
Set caster in plastic socket.
Firmly hit caster with rawhide hammer / or rubber mallet.
Note: Hit caster at same angle perpendicular to leg.



Step 1
Stabilize the chair upside down—
use care and caution not to drag
on any surface. This will create
finishing and/or upholstery issues.



Step 4
Remove caster and package for safekeeping—do not leave on floor—safety hazard.



Step 7
Attach caster until seated. There will be some up and down movement of the caster in the socket— approximately 1/8" play. Caster is correctly seated when it can not be pulled out of the plastic socket. Use care when hitting caster—these can become a wedge and split the leg if you are overly aggressive.



Step 2 Insert claw/screwdriver between metal caster collar and plastic socket.



Step 5
Visually inspect plastic socket in leg—we want a fully intact socket. If these are cracked or broken, they will need replaced, these can be removed and re-set with staples.