

Stackable Chair Transportation and Proper Use of Gasser Handtrucks

It is recommended that our stackable chairs be transported with Gasser transport equipment. The most popular of these is the HT-22 for our standard SE/ MSE/ OSE Series chairs. **NOTE: Use the HT-24 for our KL Series chairs and chairs equipped with Finger Grips.**



With nose extension of handtruck level (parallel with floor), slide handtruck under stacked chairs. (shown with HT-22 Handtruck).



Continue to slide leveled handtruck under stacked chairs until horizontal back supports on handtruck make full contact with the outside back of the lower stacked chair.



Place one foot on rear axle of handtruck and opposite hand on top of upper chair's backrest. Pull back on backrest of upper chair and handle of handtruck at same time to elevate chairs into the transport position.



CAUTION
DO NOT attempt to slide handtruck under chairs without first having nose extension at a level position.



CAUTION
DO NOT attempt to tilt stacked chairs without having handtruck in full contact with lower chair's outside back.



CAUTION
DO NOT attempt to tilt handtruck until nose extension is pulled out fully from beneath lower chair.



For the KL Series chairs and chairs with Finger Grips, use the HT-24 Handtruck with Backrest Pad.